

“L” SHAPED A-1400-PT
FLUID END MODULE AND ACCESSORIES 液力端

| Item | Part No. | Description | Qty per Pump |
|------|---------------|---|--------------|
| | LA-8488-1A | Complete Assembly 阀箱总成 | 3 |
| | LA-8488-1 | Fluid Module, Discharge - Studded (included items 1-5)排出阀箱带栓母 (包括第 1 到 5 项) | 3 |
| 1 | | Fluid Module - Discharge 排出阀箱 | 3 |
| 2 | LA-4016-96 | Stud w/Nut - Frame 螺栓带母 | 12 |
| 3 | LA-4016-97 | Stud w/Nut - Suction Module 螺栓带母 | 18 |
| 4 | LA-4016-3 | Stud w/Nut - Discharge Manifold 螺栓带母 | 12 |
| 5 | LA-4015-2 | Stud w/Nut - Valve Cover 螺栓带母 | 72 |
| | LA-8488-2 | Fluid Module, Suction - Studded (included items 5-6)吸入阀箱带栓母 (包括第 5 到 6 项) | 3 |
| 6 | | Fluid Module - Suction 吸入阀箱 | 3 |
| 7 | LA-2988 | Seal - Module 阀箱密封圈 | 3 |
| 8 | LA-10-300-201 | Seal - Suction Manifold 吸入管汇密封圈 | 3 |
| 9 | LA-8488-5 | Dowel Pin 定位销 | 6 |
| 10 | LA-4475 | Threaded Flange 阀盖法兰 | 6 |
| 11 | LA-4575 | Screw Gland 阀盖压筒 丝箱盘根盒 | 6 |
| | LA-4675-1A | Valve Cover Plug Assembly (included items 12-15)缸盖堵头总成 (包括第 12 到 15 项) | 6 |
| 12 | LA-4675-1 | Plug - Valve Cover 缸盖堵头 | 6 |
| 13 | LA-4775 | Valve Guide 导向架 | 6 |
| 14 | LA-4018-88 | Screw - Valve Guide 导向架螺丝 | 12 |
| 15 | LA-4700-1 | Insert - Valve Guide 导向套衬套 | 6 |
| 16 | LA-P129 | Seal - Valve Cover Plug 缸盖堵头密封圈 | 3 |
| 17 | LA-6488-1 | Liner Retainer Flange 缸套调整法兰 | 3 |
| 18 | LA-4017-4 | Capscrew - Liner Retainer 缸套调整螺丝 | 24 |
| 19 | LA-6588-1 | Nut - Liner Retainer (Large OD Liner, LA-0284-XX)缸套调整螺母 (缸套大外径) | 3 |
| 20 | LA-8488-7 | Set Screw - Liner Retainer 缸套调整螺丝套 | 9 |
| 21 | LA-8488-4 | Plate - Wear 耐磨垫 | 3 |
| 22 | LA-2974-1 | Seal - Wear Plate 耐磨垫密封圈 | 3 |

"L" Shaped

A-1400-PT

FLUID END MODULE
AND ACCESSORIES

